

CLIK-CLIK™ Magnetic Hanging System Instructions

step 1




MAGMOVER™
(dual model)

MAGPOLE™

Thread a MagMover onto a MagPole.

step 2




CLIKMAGNET™

LOOPLINE™

YOUR SIGN OR DISPLAY


Attach ClikMagnets™ to item you wish to hang with reusable LoopLine™ that never requires knotting. Just count loops to ensure level suspension every time!

step 3



Place the ClikMagnets on your MagMover.

step 4



Extend the MagPole to the ceiling. Release one ClikMagnet upon contact to metal (T-bar or girder), suspending the item then walk to the next location and repeat.

To remove: capture ClikMagnet's™ attached ring with MagMover™ corkscrew; pull safely down for reuse.